



## Backup Video Guide


TVI DVR MODELS

## Backing Up By Normal Video Search

The record files can be backed up to various USB devices, such as USB flash drives, USB HDDs, and USB writer.

To get started, access the Export Interface.

1. Right click on the screen.



2. Click on **Menu**.
3. Click on **Export**.




4. Click on the **Normal** tab.

- Set the **Search Conditions**.
- Click on **Search**.



- The Search Result Interface will open. Click on the **file** you want to open.



- As files are clicked, the total size of the files selected will be displayed in the lower-left corner of the window.
- Click on  to play the record file.
- Click on **Export** to start backup. The export using USB Flash Drive interface will open.

11. Confirm device to be backed up to.




12. If the device is not recognized, click on **Refresh**.

13. If needed, click **Format** to format the device.

14. Click on **Export** to start backup.


15. When all files are exported, a pop-up window will display **Export Finished**.

16. Check the backup result. Choose the file in the Export interface and click on  to view it. The Player will be automatically exported during the file export.

## Backing Up By Event Search

The event-related recording files can be backed up to various USB devices, such as USB flash drives, USB HDDs, and USB writer. To get started, access the Event Interface.

1. Right click on the screen.



DS-7200 Series

DS-7300 and DS-8100 Series

2. Click on **Menu**.

3. Click on **Export**.




4. Click on the **Event** tab.



5. Set the **Search Conditions**, such as Motion, Alarm Input, Line Crossing Detection or Intrusion Detection. Be sure to include the dates and times in the search.
6. Click on **Search**.



7. The Search Result Interface will open. Click on the **file** you want to open.



8. If back up without details is desired, click on **Quick Export**.

9. To view details of the search result, click on **Details**.

10. In the Details Interface, select the **files** to export.



11. As files are clicked, the total size of the files selected will be displayed in the lower-left corner of the window.

12. Click on **Export**. The export using USB Flash Drive interface will open.




13. Confirm device to be backed up to.

14. If the device is not recognized, click on **Refresh**.

15. If needed, click **Format** to format the device.

16. Click on **Export** to start backup.

17. When all files are exported, a pop-up window will display **Export Finished**.

18. Check the backup result. Choose the file in the Export interface and click on  to view it. The Player will be automatically exported during the file export.

