




## Playback Recording Guide

XLE NVR MODELS

## Playback

Playback the record files of a specific channel in the live view menu. Channel switch is supported.

### Instant playback by channel

1. Choose a channel under live view
2. Click on  in the shortcut operation menu.


**Note:** Only files recorded during the past five minutes on this channel will be played back.



Instant Playback Interface

### Playback by channel

1. Enter the **Playback** menu.
2. Right click on a **channel** in live view mode. The following menu will pop up.



3. Select **Playback** from the menu.

4. Click on **Play** to play back recorded files of the channel under single-screen live view.  
Under multi-screen live view, record files of the selected channel will be played back.

**Note:** Pressing numerical buttons will switch playback to related channels during playback process.

### Playback Management

1. Toolbar in the bottom part of Playback interface can be used to control playing process.
2. Click on the Check boxes of the channel or channels if you want to switch playback.

